AASKIN
Smart Life Simplified



SMART PLUG

OPERATING MANUAL

Kindly review the complete operating manual in detail before setting up the device

Track Power Consumption
Surge Protection
Schedules And Timers
Voice Control
Retrofit Design
App Control
Wi-Fi Inbuilt
NFC Support

SAFETY PRECAUTION AND PREREQUISITES

- Ensure that the steps mentioned in the installation guide are abided by throughout the installation process.
- Do not modify the device unless recommended by the technician sent by the manufacturer.
- Do not operate with wet or moist hands as it may cause electrocution.
- The device should be placed in a dry area, away from moisture & water.
- Turn off the power supply before connecting the Smart Plug or Heavy Duty plug to the 16A socket.

ABOUT SMART PLUG

Smart Plug is a smart device that enables you to automate any heavy-duty appliance. With this device, you can turn on/off an appliance at one tap on your smartphone and create a workflow for the same so that the appliance starts or stops working at the scheduled time.

FEATURES

Retrofit Design: It can be plugged into any 16 A Indian Socket.
Robust Design: Advanced firmware and rugged hardware design for long-lasting performance.
Built-in S-Wi-Fi: Equipped with secure WiFi that controls appliances from anywhere.
Voice Command: Compatible with all voice assistants such as Alexa, Bixby, Google Assistant, Siri and more.
Surge Protection: The Smart Plug can detect low and high voltages and accordingly cut off the power supply.
Timer: Create a timer to cut off the power supply after a certain amount of time.
Workflow And Schedules: Create schedules and workflows so that you don't have to touch your smartphone or give a voice command.
Monitor Power Usage: You can monitor how much power a particular appliance consumes and use it accordingly.

TECHNICAL SPECIFICATIONS

Power Input: 240V AC, 50/60Hz
Total Power Input: 16A
Maximum Resistive Load: 2500W
Maximum Inductive Load: 1000W
Typical Standby Power: <0.8W
Maximum Current Per Channel: 16A
Power Measurement Accuracy: ±5W

Operating Distance From Wi-Fi Router: upto 30 m (depends on the router and its placement)
Operating Temperature: 0° to 70° C
Number Of Channels: 1
Socket Type: Indian Model
Plug Type: Indian 16 A Model
Dimensions: 61.8 mm x 99 mm x 42 mm
Pin Standard: BS 546 Type M (Indian Standard large three-pin)
Socket Standard: BS 546 Type D & M Combo (Indian Standard large and small three-pin)
Communication Wi-Fi: Connects to 2.4 GHz, Wi-fi 802.11/b/g/n

DEVICE SETUP

- Plug-in the smart remote in any USB socket or phone charger available in the room.
- Please note that electric fluctuations inside the switchboard may at times hinder optimal device performance.

CONFIGURE SMART PLUG TO THE MOBILE APP

It is mandatory to use a Wi-Fi router to configure the device.
If you are using mobile data, turn it off and switch to Wi-Fi.
Ensure that you are following the steps for configuration, in the same sequence, mentioned in the operating manual.

AASKIN

Step 1

- Download the APP.
- The app is available in Google Play and Apple's App Store.
- Create an account and log in.

Step 2

- Once logged in, set up your 'HOME' by clicking on the 'NEW HOME' button.
- If you have already created a 'HOME', skip to 'Step 3'.
- To create a home, pick a name and location and click on 'CREATE HOME'.
- There are two ways to provide 'HOME' access to your family members and relatives.
- 1. Go to SETTINGS > HOMES > MY HOME > USERS. When you tap on users, you get an option to add a user. Enter the email ID or phone number of the family member to Provide them with the access.

- 2. Ask your family members to 'JOIN HOME' when they are creating an account. It allows them to send you a request to add them as a user by entering your email ID or phone number. As a request arrives at your phone or email, you can provide them with access once approved.

Step 3

- To set-up the switch device, Go to 'SETTINGS > DEVICES'
- Tap on the + button
- Out of the products list, Select SMART PLUGS > SMART PLUG and tap on NEXT.
- Ensure that the device is reset (by default it will be in reset mode) and tap on NEXT.

Step 4

- Ensure that the mobile data is disconnected.
- To connect your mobile phone to the device's hotspot, tap on the GO TO WI- FI SETTINGS shown at the bottom of your mobile screen.
- Make sure that when you're connecting your device to your phone, the device must be set to reset mode (by default it will be in reset mode) i.e. The Light should be blinking.
- If not in reset mode, Turn the main power of the device OFF and ON 14 times. The light will start blinking indicating that LED Strip has been set to reset mode.
- Now find and select the device wi-fi – chroma_****, in the list of the wi-fi network.
- Return to the app (NOTE: not by minimize button instead just press back), you will find options to connect to your home wi-fi from the app, select and ENTER THE PASSWORD > CONFIRM PASSWORD and wait for the notification "configuration done! ", tap on NEXT.
- Now NAME YOUR DEVICE AND ASSIGN TO ROOM > tap on CREATE DEVICE.
- You will receive a notification "SUCCESS".

Step 5

- Once as the device connects, you will see a notification 'CONFIGURATION SUCCESSFUL' - tap on NEXT to proceed.
- Once you tap on 'NEXT', you get an option 'ASSIGN TO A ROOM' where you add the device to a particular room (where the device is located).
- Also, you get an option to 'NAME YOUR DEVICE', then click on 'CREATE DEVICE'.
- After you create the device, you get a notification "SUCCESSFUL - YOUR DEVICE IS ADDED TO THE HOME", Go to Switches tab to start using switches (2nd icon in the navigation bar placed below).

CONTROLLING THE APPLIANCE

- To test the appliance and the switch, go to 'DEVICES' in the app and click on your '***Room', tap on 'SWITCH ON' or the device name you created to test the device.
- Once you tap on the option, the device will start working.

- At the bottom of the switch section, you can see the 'RUNNING TIME' of the appliance, which allows you to check and manage your power accordingly.
- You can tap on the device icon multiple times to see if the device is working smoothly or not.

DELETING A DEVICE

- To remove the device from your list of devices.
- Go to **Settings> Devices**, select the device you want to remove and at the bottom of the device information, you get an option to 'DELETE DEVICE'.

FACTORY RESET

- To reset the device, toggle the switch on and off seven times within 7 seconds. This will remove the device Wi-Fi from your app.
- The Wi-Fi network of the device will be again visible in the list of available Wi-Fi networks.
- To reconfigure, you can follow the configuration steps from '**Step 3**' mentioned above.

DISCLAIMER

- In case the device is not working within the warranty period, and the user modified the product without prior notice, the device is not applicable under warranty services.

Devices labelled with this symbol should not be disposed of with other household wastes. It shall be handed over to the applicable collection point for the recycling of waste electrical and electronic equipment.

Works Well With

Alexa | Google Assistant | Siri | Google Home

Available on the App Store

GET IT ON Google Play

Designed And Manufactured By
AASKIN AUTOMATION PVT LTD
www.aaskin.in

Customer Support
Email: support@aaskin.in
Call: 0824 350 1133

Designed By Qapfy.com